

Selva de Mar, 122-128
08020 – BARCELONA
ESPAÑA
Tel .: 34-93 308 31 54
Fax.: 34-93 303 38 73
e-mail: jemi@jemi.es
<http://www.jemi.es>


SPARE PARTS ELECTRICAL COOKER

MODEL 614-E EV

EDITION September 2012




01 ELECTRICAL COOKER 600 EV SERIES




Ref.	Denominación	Código
1	SWITCH BOARD 4 POSITIONS	240045
2	GREEN PILOT	240048
3	SWITCHBOARD KNOB (0-1-2-3) EV	996094

02 ELECTRICAL COOKER 600 EV SERIES




Ref.	Denominación	Código
1	CONTACTOR TM 230V. * LC1D09P7	240021
2	THERMOSTAT KNOB (0-1-2-3-4-5-6-7-8) EV	996095
3	GREEN PILOT FLUORINE D1304 380V. 1304380VFB	240048
4	AMBER PILOT D1304 380V. 1304380AB	240049
5	SWITCH BOARD TWO POSITIONS FOR OVEN	240020
6	ELECTRICAL BLOCK WEID SAK 6N/35 KRG * 038052	240204
7	SWITCH BOARD SB 30-300°C	998165
8	ADJUSTABLE THERMOSTAT FOR OVEN 284°C	241162

03 ELECTRICAL COOKER 600 EV SERIES




Ref.	Denominación	Código
1	SET OF CABLES FOR PLATES 1-2 600/700 SERIES	970014
2	SET OF CABLES FOR PLATES 3-4 600/700 SERIES	970015

04 ELECTRICAL COOKER 600 EV SERIES



Ref.	Denominación	Código
1	OVEN HEATER (BOTTOM PART) S-600 EV 3000W230V	241149
2	PLATE OF Ø 220 MM 2600W AT 400V	240042
3	PLATE OF Ø 180 MM 2000W AT 400V	240041
4	OVEN HEATER (TOP PART) S-600 EV 3000W230V	241150
5	SET OF HEATER CABLES (TOP PART) 411E/741E	970003
6	SET OF HEATER CABLES (BOTTOM PART) 411E/741E	970004
7	HEATER BRIDGE	240238

05 ELECTRICAL COOKER 600 EV SERIES



Ref.	Denominación	Código
1	SET OF INLET ELECTRICAL CURRENT FOR PLATES 1-3	970010
2	MAIN INLET ELECTRICAL CURRENT 4X6	240133
3	SET OF INLET ELECTRICAL CURRENT FOR PLATES 2-4	970011

06 ELECTRICAL COOKER 600 EV SERIES



<i>Ref.</i>	<i>Denominación</i>	<i>Código</i>
1 -2	SET OF OVEN HINGE	920600